

## PRODUCT SPECIFICATIONS RE-GFILT-LG-A1 GAS FILTER - LARGE - A1



PRODUCT CODE: RE-GFILT-LG-A1 PRODUCT DESCRIPTION: Gas Filter Cartridges – Large – A1 for Half Mask Respirator with Double Cartridge

## MATERIALS AND FEATURES

REBEL GAS FILTER – Large – A1 gas cartridges are used in conjunction with REBEL REUSABLE HALF MASK DOUBLE CARTRIDGE respirators (RE-HALMADBL), filtering organic gases and vapours.

## CERTIFICATION

EN/ISO REQUIREMENT	EN14387: 2004 + A1:2008
SABS	SANS 54387:2007
NRCS	NRCS: NRCS/8072/0448
CE REQUIREMENT	CE 2834 Regulation (EU) 2016/425

## SPECIAL INSTRUCTIONS/WARNINGS

Please read user instruction in full before making use of these gas filter cartridges - refer to www.rebelsafetygear.com

Only to be used in conjunction with REBEL Half Mask Respirator with Double Cartridge – supplied separately.

If either product is used with another brand, we cannot be held responsible for the efficacy of the product.

Do not use where:

- Oxygen concentration is less than 19.5%.
- There is in an oxygen-enriched environment where oxygen concentration >23.5%.
- Contaminants or their concentrations are unknown or are known to be immediately dangerous to life or health. Particulate or gas
- concentrations exceed levels fixed by the applicable health and safety regulations.
- Not to be used for firefighting.
- Do not use in explosive atmospheres.

These cartridges do not supply oxygen. DO NOT use in oxygen deficient atmospheres (e.g. tanks or other poorly ventilated areas).

A Gas Filter must be replaced once chemical breakthrough can be determined by smell, taste or any other means. Please read the user instructions to determine when they must be replaced.

The REBEL GAS FILTER CARTRIDGE is for use with TWIN filter masks only.



CARE/STORAGE	
STORAGE INSTRUCTIONS	<ul> <li>Gas filter shall be stored in a dry, clean, low humidity environment.</li> <li>Store between temperatures of -10 and +30 degrees Celsius, and where relative humidity is &lt;70%.</li> </ul>
CARE INSTRUCTIONS	<ul><li>The exterior of the filter can be cleaned with the use of a dry cloth.</li><li>Solvents must not be used for cleaning and care should be taken to ensure no water enters the filter.</li></ul>
SHELF LIFE	<ul> <li>5 years from date of manufacturing, provided it is still in its original, sealed packaging.</li> <li>The expiry date of each item is indicated on the packaging and on the cartridge.</li> </ul>
DISPOSAL	<ul> <li>All industrial waste should be disposed of correctly according to local regulations and good disposal practice.</li> <li>Respiratory protective devices should be disposed of considering the hazardous substance they were used for.</li> <li>Please consider recycling.</li> </ul>
OTHER INFORMATION	
SIZING	One size.
PACKAGING	1 pair per packet, 30 packets per carton.